



Części niezbędne do użycia MUFY HERMETYCZNEJ




Elementy niezbędne przy czynnościach montażowych:


- śrubokręt
- 2x klucz płaski (19)

UWAGA! Lista produktów, z którymi współpracują wybrane akcesoria dostępna jest na stronie


1. Wprowadź przewody przez nakrętki dociskające (A) do korpusów mufy (B, C).




2. Połącz przewody np. przy użyciu kostki elektrycznej i umieść miejsce łączenia wewnątrz korpusu większego (B).




3. Przkręć korpus mniejszy (C) do korpusu większego (B).




4. Dokręć nakrętki dociskające (A) przy użyci dwóch kluczy płaskich (19).





Parts needed to assemble the WATERPROOF COUPLER




Tools needed for mounting:


- screwdriver
- 2x flat wrench (19)

NOTE! A list of products corresponding with the selected accessories is available


1. Run the cables through the plastic nuts (A) into the coupler bodies (B, C).



2. Connect the cables using e.g. a connection block and place the connection inside the large body (B).



3. Connect the small body (C) with the large body (B).



4. Tighten the plastic nuts (A) with two flat wrenches (19).

