



**Części niezbędne do skonstruowania oprawy na bazie profilu LIT-L**



Listwa montażowa (A)



Zaślepki (B)



Profil (C)



Zaślepki (D)



Osłona (E)



Taśma LED (F)



Sznur silikonowy (G)


**Elementy niezbędne przy czynnościach montażowych:**

- wiertarka
- wkrętarka / śrubokręt
- wkręty
- piła do metalu
- klej
- gips
- farba


**UWAGA!** Wszystkie taśmy LED powinny być podłączone do zasilacza 12 V lub 24 V.

**WAŻNE:** Instrukcja przedstawia najbardziej podstawową formę montażu.
Więcej metod i powiązanych akcesoriów znajdziesz na stronie


**1.** Przytnij listwę (A) do żądanej długości a profil (C) o min. 2 cm krócej. Umożliwi to założenie zaślepek i prowadzenie przewodu wewnątrz oprawy.





**2.** Wywierć w listwie montażowej (A) otwory na wkręty oraz na przewody zasilające.





**3.** Przykręć listwę montażową (A) do powierzchni. Użyj wkrętów odpowiednich do danego materiału (drewno, kartongips itp.). Wyprowadź przewody zasilające.





**4.** Załóż zaślpeki (B) na listwę montażową (A) i pokryj całość gładzią gipsową.





**5.** Zainstaluj taśmę LED (F), wyprowadź przewód i załóż osłonę (E) w profilu (C). Załóż zaslepki (D). Przewód może być prowadzony przez otwór nawiercony w profilu lub w zaślepce.





**6.** Zamontuj profil (C) w listwie montażowej (A) i zabezpiecz sznurem silikonowym (G).





**Parts needed to mount the LIT-L extrusion**



Mounting strip (A)



End caps (B)



Extrusion (C)



End caps (D)



Cover (E)



LED strip (F)



Silicone cord (G)


**Tools needed for mounting:**

- drill
- dcrewdriver
- screws
- metal saw
- glue
- plaster
- paint


**WARNING!** All LED strips should be connected to a 12 V or 24 V power supply.

**IMPORTANT:** The mounting instructions present the basic form of assembly.
More methods and related accessories can be found at


**1.** Cut the mounting strip (A) to the required length and the extrusion (C) min. 2 cm shorter. This will enable mounting end caps and running the cable inside the fixture.





**2.** Drill screw holes and holes for power cables in the mounting strip (A).





**3.** Attach the mounting strip (A) to the mounting surface with screws suitable for the material (wood, plasterboard etc.). Feed the power cables.




**4.** Insert the end caps (B) into the mounting strip (A) and cover all with plaster finish.




**5.** Install the LED strip (F), lead out the cable and insert the cover (E) into the extrusion (C). Insert the end caps (D). The cable can be run through a hole drilled in the extrusion or in the end cap.




**6.** Mount the extrusion (C) in the mounting strip (A) and secure with the silicone cord (G).

