


Części niezbędne do skonstruowania oprawy na bazie profilu PDS-MDF



Profil (A)



Taśma LED (B)



Osłona (C)



Zaślepka (D)

Elementy niezbędne przy czynnościach montażowych:


- taśma mocująca

UWAGA! Wszystkie taśmy LED powinny być podłączone do zasilacza 12 V lub 24 V.


WAŻNE: Instrukcja przedstawia podstawową formę montażu.
Więcej metod i powiązanych akcesoriów znajdziesz na stronie


Montaż oprawy na bazie profilu PDS-MDF

1. Zainstaluj taśmę LED (B) w profilu (A), załóż osłonę (C) i zaślepki (D).



2. Wyprowadź przewód zasilający. Na górną powierzchnę profilu (A) przyklej taśmę mocującą. Całą oprawę zamontuj w wybranym miejscu.





Parts needed to mount the PDS-MDF extrusion



Extrusion (A))



LED strip (B)



Cover (C)



End cap (D)


Tools needed for mounting:

- mounting tape

WARNING! All LED strips should be connected to a 12 V or 24 V power supply.

IMPORTANT: The mounting instructions present the basic form of assembly.
More methods and related accessories can be found

1. Install the LED strip (B) in the extrusion (A), insert the cover (C) and the end caps (D).



2. Feed the power cable. Attach the mounting tape to the upper part of the extrusion (A). Attach the entire fixture to the chosen location.

