


Części niezbędne do skonstruowania oprawy na bazie profilu PDS-ZM



Profil (A)



Taśma LED (B)



Osłona (C)



Zaślepki (D)



Sprężyna (E)


Elementy niezbędne przy czynnościach montażowych:

- klej do montażu


UWAGA! Wszystkie taśmy LED powinny być podłączone do zasilacza 12 V lub 24 V.

WAŻNE: Instrukcja przedstawia podstawową formę montażu.
Więcej metod i powiązanych akcesoriów znajdziesz na stronie


1. Zainstaluj taśmę LED (B) w profilu (A), załóż osłonę (C), zaślepki (D) i sprężyny (E).




2. Podłącz przewód zasilający. Wprowadź sprężyny (E) do otworów.



3. Dopchnij profil do powierzchni.





Parts needed to mount the PDS-ZM extrusion



Extrusion (A)




LED strip (B)



Cover (C)



End caps (D)



Spring (E)


Tools needed for mounting:

- mounting glue


WARNING! All LED strips should be connected to a 12 V or 24 V power supply.

IMPORTANT: The mounting instructions present the basic form of assembly.
More methods and related accessories can be found

1. Install the LED strip (B) in the extrusion (A), insert the cover (C), end caps (D) and springs (E).



2. Connect the power cable. Insert the springs (E) into the holes.



3. Push the extrusion to the surface.

