



Elementy niezbędne przy czynnościach montażowych:


- wiertarka

UWAGA! Lista produktów, z którymi współpracują wybrane akcesoria dostępna jest na stronie


1. Wywierć w ściance kartonowo-gipsowej otwór o średnicy 10 mm.




2. Wsuń zestaw M3 w nawiercony otwór.




3. Kręcąc głowicą, dokręć śrubę do oporu - doprowadzi to do rozwarcia kołka rozporowego i zablokuje zestaw w ścianie.




4. Włóż wybraną oprawę w mocownik.



5. UWAGA! Pozycję oprawy na wysięgniku można regulować w zakresie 300°.






Tools needed for assembly:


- drill

NOTE! A list of products corresponding with the selected accessories is available


1. Drill a hole in the drywall 10mm in diameter.




2. Insert the M3 mounting set into the drilled hole.



3. Turn the head to tighten the screw to the fullest – as it tightens it will expand the drywall anchor and fix the mounting set in the drywall.



4. Insert selected fixture/ extrusion into the mounting bracket.



5. ATTENTION! POSITION OF THE FIXTURE CAN BE REGULATED on the arm in a range of 300 degrees.

