


Części niezbędne do skonstruowania oprawy na bazie profilu TRIADA



Profil (A)

Taśma LED (B)



Osłona (C)



Zaślepka (D)


Elementy niezbędne przy czynnościach montażowych:

- klej montażowy


UWAGA! Wszystkie taśmy LED powinny być podłączone do zasilacza 12 V lub 24 V.

WAŻNE: Instrukcja przedstawia podstawową formę montażu.
Więcej metod i powiązanych akcesoriów znajdziesz na stronie


1. Zainstaluj taśmy LED (B) w profilu (A), załóż osłony (C) i zaślepki (D).




2. Wyprowadź przewód zasilający. Rozprowadź klej wenątrz kanału montażowego



3. Podłącz zasilanie do paska LED i umieść profil (A) w kanale montażowym.





Parts needed to mount the TRIADA-K extrusion



Extrusion (A)



LED strip (B)



Cover (C)



End cap (D)


Tools needed for mounting:

- mounting glue


NOTE! All LED strips must be connected to a 12 V or 24 V power supply.

IMPORTANT: The manual presents the simplest mounting procedure.
More mounting procedures and related accessories can be found

1. Install the LED strips (B) in the extrusion (A), insert the covers (C) and the end caps (D).



2. Feed the power cable. Spread the glue inside the mounting groove.



3. Connect power to the LED strip and mount the extrusion (A) in the mounting groove.

